

Setup S88R GT

Driver :	Date :	Track : BASE	Track temp:
Condition : Technical / Mixed / Fast		Traction : Low / Medium / High	Temperature:
Body :	Engine :	Air filter :	Exhaust :
Differential Unit : S88R. oil.		Model :	<input checked="" type="radio"/> Oil <input type="radio"/> Grease

Hard ←→Soft

Front
Toe / Gap

63 mm

Soft ←→Hard

Rear
Toe / Gap

Front		L	R
Camber:		+1°	+1°
Shim : in mm			

Rear		L	R
Camber:		-3°	-3°
Shim : in mm			

Deck		L	R
Flex	X	2°	2°
Solid		2,5°	2,5°
		3°	3°
		3,5°	3,5°

Top		Bottom
Number :	1	4
Height in mm	1	7

Top	
Number :	1
Height in mm	4

in mm	
X	12
	13
	14

in mm	
X	12
	13
	14

50 Axle Height

Front

8 Ride Height

9 Ride Height

Rear

46 Axle Height

Shocks : Progressive / Note	Tires : GRP / PMT	Transmission :	Ballance (gr) :
Oil	Driving direction clock / anti-clock	Engine : 34 / 35	Front : Center: 100 Rear:
Spring soft <-> hard	Left	Sec Crown : 62 / 63	Note :
Front : 5000	Front : M2 M2	Diff Crown : 72	
Rear : 4000	Rear : M1 M1		